



QUALITY PRODUCTS - OE PERFORMANCE

## **POWER WINDOW TROUBLE SHOOTING TIPS**

All ACI power motor products are designed to be exact replacements for the components that your vehicle was originally equipped with from the factory. The following Trouble Shooting Guide should be helpful if you encounter any problems after you have installed our products.

### **Window Won't Move**

- 1) Switch may be faulty.
- 2) Wiring: Check wiring for any signs of fraying around connector.
- 3) Weather stripping may be binding on window.
- 5) Check Fuse.
- 6) Check that battery is in good condition and connected.
- 7) Be sure ignition is in Accessory Position.

### **Window Runs Slowly**

- 1) Be sure window is seated in guides properly.
- 2) Check weather stripping for possible drag on window.
- 3) Check to see if battery is properly charged.

### **Window Vibrates When Moving**

- 1) If replacement was "Motor" only, be sure Motor gear is properly aligned with Regulator gear.
- 2) Check weather stripping for drag on window.
- 3) Be sure moving parts on regulator or window itself are not encountering interference.

### **Window Makes Noise When Moving**

NOTE: A noise level similar to the "Hum" of a small fan is expected. If louder, then:

- 1) Be sure window is seated in guides properly.
- 2) Check that screws holding regulator are tight.
- 3) Check to see if wires or cables are interfering with movement of window or regulator.

500 Industrial Blvd. • Grapevine, TX 76051 • 1-866-962-9247 • [www.aciauto.com](http://www.aciauto.com)

